

Compack Controller

Monitoring and Control Unit

SMALL WITH ALL

"All-in-one" plug-in controller. Comprehensive functionality in a small box designed for small range power systems.



COMPACK CONTROLLER

Doc 242100.400.DS3 - v7

APPLICABLE SYSTEMS

TELECOM

- CHAMELEON
- MICROPACK 48V
- MINIPACK 1U
- PLATPACK2 DC/DC IN INTERFACE

INDUSTRIAL

- MICROPACK 12V & 24V
- COMPACK INTERFACE KIT



MINIPACK 1U 1600W SYSTEM



MICROPACK 1000W CONVECTION COOLED SYSTEM



COMPACK IN INTERFACE KIT (PN 242100.900)



COMPACK IN CHAMELEON SYSTEM

KEY FEATURES

- REMOTE MONITORING VIA ETHERNET
 - SNMP (v3,v2c,v1)
 - **WEB PAGES**
 - EMAIL OF LOGS AND ALARMS
- 3 CONFIGURABLE RELAYS
- 3 MULTIPURPOSE INPUTS
 - **TEMPERATURE**
 - **SYMMETRY**
 - **DIGITAL INPUT**
- 2 LVD CONTROLLS (LVBD+LVLD)
- 12V,24V,30V,48V & 60V SUPPORTED
- **BATTERY MONITORING**
 - AUTO/PERIODIC TEST
 - CAPACITY/QUALITY ESTIMATION
- **ELTEK SOFTWARE SUPPORTED**
 - **ELTEK NETWORK UTILITY**
 - MULTISITE MONITOR
 - **POWER SUITE**

COMPACK CONTROLLER



FOR 12V, 24V, 30V, 48V & 60V SYSTEMS

ELECTRICAL SPECIFICATIONS			
Input Voltage	9 - 75 V _{DC} , shutdown < 8.5 V _{DC} *		
Temperature Range	Nominal: -20 to +60 C (-4 to 140 F) Reduced accuracy: -40 to +70 C		
Power Consumption	3W		
MTBF	> 550, 000 hours Telcordia SR-332 Issue I, method III (a) (Tambient : 25°C)		
Ethernet port	10/100 BASE-T HP Auto MDI/MDI-X		
Relay Outputs (1,5 mm2)	Form-C (dry contact NO-C-NC), Max 75V/2A/60W breaking capacity		
Configurable Inputs (1,5 mm2)	Temperature: External NTC, "Digital": open/closed,	Temperature: External NTC, "Digital": open/closed, Analog: 0-75V, Battery Symmetry: 0-75V	
CONTROL FEATURES			
Control System	 Output Voltage Measurement Load Current Calculation Energy Calculation Load/Battery Disconnect Real Time Clock with Battery Backup Stored Site Text/ID and Messages 	o Output Voltage Measuremento Position (long/lat) for auto placement o Generator start/stop control setup o Test of Relay Outputs o Alarm grouping of events for relay outputs o Boolean AND of alarm groups	
Battery	o Battery Current Measurement o Battery Temperature Measurement Battery Testing (acc. to discharge table or set time limit) o Setup of Battery Data/Table o Battery Capacity Indication o Battery Boost Charging - Auto – Ah discharge or voltage threshold - Interval or Manual	o Temperature Compensated Charging o Charge Current Limitation o Battery Low Voltage Disconnect - Temperature dependent (optional) - Mains independent (optional)	
Rectifier	 Available information about each rectifier, e.g. serial number, version, internal temperature Individual Rectifier Current Measurement 	o Energy calculationo Efficiency Managemento Emergency Voltageo Startup delay	
	o Individual Rectifier Input Voltage	o Detailed internal alarms summary	
ALARMS / EVENTS AVAILABL		o Detailed internal alarms summary	
•			
Alarms can be set up with monitor analogue values are auto logged.	.E	er configurable. All average and peak levels on o Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System	ing of minor and major levels. Hysteresis and time delay is use o AC Mains Low (2-level) o AC Phase Voltage x3 (2-level) o "Digital" Inputs (programmable descriptions)	er configurable. All average and peak levels on o Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System Load	ing of minor and major levels. Hysteresis and time delay is use O AC Mains Low (2-level) O AC Phase Voltage x3 (2-level) O "Digital" Inputs (programmable descriptions) O Events trigger by inputs O Load Disconnect - Voltage or Timer (from mains failure) based	er configurable. All average and peak levels on O Service mode (block relays), Generator runnin Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual reset alarms. O Load Fuse	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System Load	ing of minor and major levels. Hysteresis and time delay is use O AC Mains Low (2-level) O AC Phase Voltage x3 (2-level) O "Digital" Inputs (programmable descriptions) O Events trigger by inputs O Load Disconnect - Voltage or Timer (from mains failure) based - Mains independent (optional) O Battery Voltage (4-level, optional 8-level) O Battery Used Capacity (2-level) [Ah or %] O Battery Remaining Capacity (2-level) [Ah or %]	er configurable. All average and peak levels on o Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual reset alarms. o Load Fuse o Load Current o Symmetry Failure (2-level) o Battery Quality after test (2-level) o Battery Current (4-level) o Battery Life Time (2-level) [from temperature	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System Load Battery Rectifier/Converter	ing of minor and major levels. Hysteresis and time delay is used o AC Mains Low (2-level) o AC Phase Voltage x3 (2-level) o "Digital" Inputs (programmable descriptions) o Events trigger by inputs o Load Disconnect - Voltage or Timer (from mains failure) based - Mains independent (optional) o Battery Voltage (4-level, optional 8-level) o Battery Temperature (2-level) o Battery Used Capacity (2-level) [Ah or %] o Battery Fuse o Rectifier Failure (2-level) o Rectifier Capacity (2-level)	er configurable. All average and peak levels on O Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual reset alarms. O Load Fuse O Load Current O Symmetry Failure (2-level) O Battery Quality after test (2-level) O Battery Current (4-level) O Battery Life Time (2-level) [from temperature log] O Rectifier Avg. Temperature (2-level)	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System Load Battery Rectifier/Converter DATA LOGGING	ing of minor and major levels. Hysteresis and time delay is used o AC Mains Low (2-level) o AC Phase Voltage x3 (2-level) o "Digital" Inputs (programmable descriptions) o Events trigger by inputs o Load Disconnect - Voltage or Timer (from mains failure) based - Mains independent (optional) o Battery Voltage (4-level, optional 8-level) o Battery Temperature (2-level) o Battery Used Capacity (2-level) [Ah or %] o Battery Fuse o Rectifier Failure (2-level) o Rectifier Capacity (2-level)	er configurable. All average and peak levels on o Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual reset alarms. o Load Fuse o Load Current o Symmetry Failure (2-level) o Battery Quality after test (2-level) o Battery Current (4-level) o Battery Life Time (2-level) [from temperature log] o Rectifier Avg. Temperature (2-level) o Rectifier Current Share (2-level)	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System Load Battery Rectifier/Converter DATA LOGGING Control System	ing of minor and major levels. Hysteresis and time delay is used of AC Mains Low (2-level) o AC Phase Voltage x3 (2-level) o "Digital" Inputs (programmable descriptions) o Events trigger by inputs o Load Disconnect - Voltage or Timer (from mains failure) based - Mains independent (optional) o Battery Voltage (4-level, optional 8-level) o Battery Temperature (2-level) o Battery Used Capacity (2-level) [Ah or %] o Battery Fuse o Rectifier Failure (2-level) o Rectifier Capacity (2-level) o Rectifier Capacity (2-level) o Rectifier Current (2-level)	er configurable. All average and peak levels on o Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual reset alarms. o Load Fuse o Load Current o Symmetry Failure (2-level) o Battery Quality after test (2-level) o Battery Current (4-level) o Battery Life Time (2-level) [from temperature log] o Rectifier Avg. Temperature (2-level) o Rectifier Current Share (2-level)	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System Load Battery Rectifier/Converter DATA LOGGING Control System Energy	ing of minor and major levels. Hysteresis and time delay is used of AC Mains Low (2-level) o AC Phase Voltage x3 (2-level) o "Digital" Inputs (programmable descriptions) o Events trigger by inputs o Load Disconnect - Voltage or Timer (from mains failure) based - Mains independent (optional) o Battery Voltage (4-level, optional 8-level) o Battery Temperature (2-level) o Battery Used Capacity (2-level) [Ah or %] o Battery Remaining Capacity (2-level) [Ah or %] o Battery Fuse o Rectifier Failure (2-level) o Rectifier Capacity (2-level) o Rectifier Capacity (2-level) e Rectifier Current (2-level)	er configurable. All average and peak levels on O Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual reset alarms. O Load Fuse O Load Current O Symmetry Failure (2-level) O Battery Quality after test (2-level) O Battery Current (4-level) O Battery Life Time (2-level) [from temperature log] O Rectifier Avg. Temperature (2-level) O Rectifier Current Share (2-level)	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System Load Battery Rectifier/Converter DATA LOGGING Control System Energy Battery	ing of minor and major levels. Hysteresis and time delay is used O AC Mains Low (2-level) O AC Phase Voltage x3 (2-level) O "Digital" Inputs (programmable descriptions) O Events trigger by inputs O Load Disconnect - Voltage or Timer (from mains failure) based - Mains independent (optional) O Battery Voltage (4-level, optional 8-level) O Battery Temperature (2-level) O Battery Used Capacity (2-level) [Ah or %] O Battery Fuse O Rectifier Failure (2-level) O Rectifier Capacity (2-level) O Rectifier Capacity (2-level) Event log, Data log (configurable up to 20 monitors Energy delivered from Rectifiers, Solar Charger and last 52 hours, 52 days and 52 weeks	er configurable. All average and peak levels on o Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual reset alarms. o Load Fuse o Load Current o Symmetry Failure (2-level) o Battery Quality after test (2-level) o Battery Current (4-level) o Battery Life Time (2-level) [from temperature log] o Rectifier Avg. Temperature (2-level) o Rectifier Current Share (2-level)	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System Load Battery Rectifier/Converter DATA LOGGING Control System Energy Battery Generator	ing of minor and major levels. Hysteresis and time delay is used of AC Mains Low (2-level) o AC Phase Voltage x3 (2-level) o "Digital" Inputs (programmable descriptions) o Events trigger by inputs o Load Disconnect - Voltage or Timer (from mains failure) based - Mains independent (optional) o Battery Voltage (4-level, optional 8-level) o Battery Temperature (2-level) o Battery Used Capacity (2-level) [Ah or %] o Battery Remaining Capacity (2-level) [Ah or %] o Battery Fuse o Rectifier Failure (2-level) o Rectifier Capacity (2-level) o Rectifier Current (2-level) Event log, Data log (configurable up to 20 monitors Energy delivered from Rectifiers, Solar Charger and last 52 hours, 52 days and 52 weeks 10 last battery tests detailed, number of battery of Run time in minutes and fuel consumption for the	er configurable. All average and peak levels on o Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual reset alarms. o Load Fuse o Load Current o Symmetry Failure (2-level) o Battery Quality after test (2-level) o Battery Current (4-level) o Battery Life Time (2-level) [from temperature log] o Rectifier Avg. Temperature (2-level) o Rectifier Current Share (2-level) s), Configuration Change log, Account Access log d Battery, and consumed energy by the load for the cycles for the last 52 hours, 52 days and 52 weeks last 52 hours, 52 days and 52 weeks	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System Load Battery Rectifier/Converter DATA LOGGING Control System Energy Battery Generator Model	ing of minor and major levels. Hysteresis and time delay is used of AC Mains Low (2-level) o AC Phase Voltage x3 (2-level) o "Digital" Inputs (programmable descriptions) o Events trigger by inputs o Load Disconnect - Voltage or Timer (from mains failure) based - Mains independent (optional) o Battery Voltage (4-level, optional 8-level) o Battery Temperature (2-level) o Battery Used Capacity (2-level) [Ah or %] o Battery Remaining Capacity (2-level) [Ah or %] o Battery Fuse o Rectifier Failure (2-level) o Rectifier Capacity (2-level) o Rectifier Current (2-level) Event log, Data log (configurable up to 20 monitors Energy delivered from Rectifiers, Solar Charger and last 52 hours, 52 days and 52 weeks 10 last battery tests detailed, number of battery of Run time in minutes and fuel consumption for the lognard.	er configurable. All average and peak levels on o Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual reset alarms. o Load Fuse o Load Current o Symmetry Failure (2-level) o Battery Quality after test (2-level) o Battery Current (4-level) o Battery Life Time (2-level) [from temperature log] o Rectifier Avg. Temperature (2-level) o Rectifier Current Share (2-level) s), Configuration Change log, Account Access log d Battery, and consumed energy by the load for the cycles for the last 52 hours, 52 days and 52 weeks last 52 hours, 52 days and 52 weeks	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System Load Battery Rectifier/Converter DATA LOGGING Control System Energy Battery Generator	ing of minor and major levels. Hysteresis and time delay is used of AC Mains Low (2-level) o AC Phase Voltage x3 (2-level) o "Digital" Inputs (programmable descriptions) o Events trigger by inputs o Load Disconnect - Voltage or Timer (from mains failure) based - Mains independent (optional) o Battery Voltage (4-level, optional 8-level) o Battery Temperature (2-level) o Battery Used Capacity (2-level) [Ah or %] o Battery Remaining Capacity (2-level) [Ah or %] o Battery Fuse o Rectifier Failure (2-level) o Rectifier Capacity (2-level) o Rectifier Current (2-level) Event log, Data log (configurable up to 20 monitors Energy delivered from Rectifiers, Solar Charger and last 52 hours, 52 days and 52 weeks 10 last battery tests detailed, number of battery of Run time in minutes and fuel consumption for the	er configurable. All average and peak levels on o Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual reset alarms. o Load Fuse o Load Current o Symmetry Failure (2-level) o Battery Quality after test (2-level) o Battery Current (4-level) o Battery Life Time (2-level) [from temperature log] o Rectifier Avg. Temperature (2-level) o Rectifier Current Share (2-level) s), Configuration Change log, Account Access log d Battery, and consumed energy by the load for the cycles for the last 52 hours, 52 days and 52 weeks last 52 hours, 52 days and 52 weeks	
Alarms can be set up with monitor analogue values are auto logged. Power & Control System Load Battery Rectifier/Converter DATA LOGGING Control System Energy Battery Generator Model	ing of minor and major levels. Hysteresis and time delay is used of AC Mains Low (2-level) o AC Phase Voltage x3 (2-level) o "Digital" Inputs (programmable descriptions) o Events trigger by inputs o Load Disconnect - Voltage or Timer (from mains failure) based - Mains independent (optional) o Battery Voltage (4-level, optional 8-level) o Battery Temperature (2-level) o Battery Used Capacity (2-level) [Ah or %] o Battery Remaining Capacity (2-level) [Ah or %] o Battery Fuse o Rectifier Failure (2-level) o Rectifier Capacity (2-level) o Rectifier Current (2-level) Event log, Data log (configurable up to 20 monitors Energy delivered from Rectifiers, Solar Charger and last 52 hours, 52 days and 52 weeks 10 last battery tests detailed, number of battery of Run time in minutes and fuel consumption for the lognard.	er configurable. All average and peak levels on o Service mode (block relays), Generator running Lower charge current limit, Battery test, Boos Inhibit, Emergency low voltage, Clear manual reset alarms. o Load Fuse o Load Current o Symmetry Failure (2-level) o Battery Quality after test (2-level) o Battery Current (4-level) o Battery Life Time (2-level) [from temperature log] o Rectifier Avg. Temperature (2-level) o Rectifier Current Share (2-level) s), Configuration Change log, Account Access log d Battery, and consumed energy by the load for the cycles for the last 52 hours, 52 days and 52 weeks last 52 hours, 52 days and 52 weeks	

Doc 242100.400.DS3 - v7

Specifications are subject to change without notice

Eltek © 2016 – <u>www.eltek.com</u>

Phone: +47 32 20 32 00